



BAR LED 24x3W

Quickstart Manual

1. Menu functions description

Display	Range	Function
A001	001-512	2CH DMX adress setup
C001	001-512	3CH DMX adress setup
d001	001-512	4CH DMX adress setup
E001	001-512	6CH DMX adress setup
H001	001-512	7CH DMX adress setup
L001	001-512	12CH DMX adress setup
P001	001-512	24CH DMX adress setup
r255	000-255	Red
g255	000-255	Green
b255	000-255	Blue
FF00	00-20	Strobe (slow-fast)
1J00	00-20	Effect 1(slow to fast)
2J00	00-20	Effect 2 (slow to fast)
3J00	00-20	Effect 3 (slow to fast)
4J00	00-20	Effect 4 (slow to fast)
5J00	00-20	Effect 5 (slow to fast)
6J00	00-20	Effect 6 (slow to fast)
7J00	00-20	Effect 7 (slow to fast)
8J00	00-20	Effect 8 (slow to fast)
9J00	00-20	Effect 1 to 8
1d00	00-20	Red pulse (slow to fast)
2d00	00-20	Green pulse (slow to fast)
3d00	00-20	Blue pulse (slow to fast)
4d00	00-20	Magenta pulse (slow to fast)
5d00	00-20	Yellow pulse (slow to fast)
6d00	00-20	Red, Green, Blue, Magenta, yellow (slow to fast)
SU00	00-20	Sound react mode (slow to fast)

2ch	Range	Function
1	000-011	off
	012-023	Red
	024-035	Green
	036-047	Blue
	048-059	Yellow
	060-071	Magenta
	072-083	Cyan
	084-095	White
	096-107	Effect 1
	108-119	Effect 2
	120-132	Effect 3
	133-143	Effect 4
	144-155	Effect 5
	156-167	Effect 6
	168-179	Effect 7
	180-191	Effect 8
	192-203	Effect 9
	204-217	Effect 10
	218-227	Effect 11
	228-239	Effect 12
	240-251	Effect 13
	252-255	Sound mode
2	000-255	Speed (slow to fast)

3ch	Range	Function
1	000-255	Red
2	000-255	Green
3	000-255	Blue

4ch	Range	Function
1	000-255	Dimmer
2	000-255	Red
3	000-255	Green
4	000-255	Blue

7ch	Range	Function
1	000-255	Dimmer
2	000-255	Red
3	000-255	Green
4	000-255	Blue
5	000-007	off
	008-255	Strobe
6	000-011	off
	012-023	Red
	024-035	Green
	036-047	Blue
	048-059	Yellow
	060-071	Magenta
	072-083	Cyan
	084-095	Bialy
	096-107	Effect 1
	108-119	Effect 2
	120-132	Effect 3
	133-143	Effect 4
	144-155	Effect 5
	156-167	Effect 6
	168-179	Effect 7
	180-191	Effect 8
	192-203	Effect 9
	204-217	Effect 10
	218-227	Effect 11
	228-239	Effect 12
	240-251	Effect 13
	252-255	Sound mode
7	000-255	Speed (slow to fast)

12ch	Range	Function	Section
1	000-255	R dimmer	1
2	000-255	G dimmer	
3	000-255	B dimmer	
4	000-255	R dimmer	2
5	000-255	G dimmer	
6	000-255	B dimmer	
7	000-255	R dimmer	3
8	000-255	G dimmer	
9	000-255	B dimmer	
10	000-255	R dimmer	4
11	000-255	G dimmer	
12	000-255	B dimmer	

24ch	Range	Function	Section
1	000-255	R dimmer	1
2	000-255	G dimmer	
3	000-255	B dimmer	
4	000-255	R dimmer	2
5	000-255	G dimmer	
6	000-255	B dimmer	
7	000-255	R dimmer	3
8	000-255	G dimmer	
9	000-255	B dimmer	
10	000-255	R dimmer	4
11	000-255	G dimmer	
12	000-255	B dimmer	
13	000-255	R dimmer	5
14	000-255	G dimmer	
15	000-255	B dimmer	
16	000-255	R dimmer	6
17	000-255	G dimmer	
18	000-255	B dimmer	
19	000-255	R dimmer	7
20	000-255	G dimmer	
21	000-255	B dimmer	
22	000-255	R dimmer	8
23	000-255	G dimmer	
24	000-255	B dimmer	

3. Specs

Specification	
Power consumption	80 W
Supply voltage	110 - 240 V
Supply frequency	50 - 60 Hz
Diode type	RGB
Diode number	24
Diode power	3W
Display	LCD
Control	4 buttons
Dimming	Smooth 0-100%
DMX channels	2/3/4/6/7/12/24
Beam angle	25°
Control	DMX, Auto, Master/Slave, Sound
DMX IN	XLR
DMX OUT	XLR
Enclosure	ABS
Cooling	no